

# Addendum

HART® Communication with the  
X2200 UV Flame Detector

---



# Table of Contents

Interconnecting the HART Communicator with the Detector . . . . .	1
HART Device Description Language . . . . .	3
Detector Wiring . . . . .	3
HART Menu Structure . . . . .	4
X2200 Root Menu . . . . .	5
Device Info Menu . . . . .	5
General Info Menu . . . . .	6
HART Info Menu . . . . .	7
HART PV Menu . . . . .	8
Condensed Status . . . . .	9
Status Info Menu . . . . .	10
Hardware Menu . . . . .	11
oI Menu . . . . .	12
Detector Settings . . . . .	13
History Menu . . . . .	13
Command Menu . . . . .	14
HART Command Menu . . . . .	15
Device Setup Menu . . . . .	15
Configuration Menu . . . . .	16
Calibration Menu . . . . .	16
Write Protect . . . . .	17
HART Setup . . . . .	18
Real Time Clock . . . . .	18

---

**AUTOMATIC**

---

**HART Communication  
with the X2200  
UV Flame Detector**

Digital communication with the X2200 allows the operator to monitor the status of the detector, determine factory settings, adjust field settings, and initiate field tests. This addendum provides guidance for establishing HART communication, and describes the HART menu structure when using the X2200 with a HART Handheld Communicator, a PC, or other process interface device that supports Device Description Language (DD).

**NOTE**

*A minimum level of understanding with regard to the operation and navigation of the HART Communicator is required. Refer to the instruction manual supplied with the HART Communicator for basic operating instructions.*

**INTERCONNECTING THE HART COMMUNICATOR WITH THE DETECTOR****Point-to-Point Mode**

The HART Communicator can connect to the X2200 at any wiring termination point in the analog output signal loop. Connect the HART communicator in parallel with the X2200 analog signal or load resistor. The HART connections are non-polarized.

**IMPORTANT WIRING NOTE**

The HART Communicator does not measure loop current directly, but instead reads a voltage signal across a resistance (250 ohms) in the loop. The recommended connection point is across the input impedance of the signal receiver (PLC), which is a nominal 250 ohms. See Figures 1 to 4. If testing/programming on a bench, a 250 ohm load resistor must be used. See Figure 5.

Switch on the HART Communicator. If a device is found, the HART Communicator displays the Main menu. If no device is found, check the connections and verify the presence of a minimum of 250 ohms load resistance in series in the loop.

9	mA +	19	mA -	29	SPARE 1
8	mA + REF	18	mA - REF	28	SPARE 1
7	COM FIRE	17	COM FIRE	27	COM AUX
6	NO FIRE	16	NO FIRE	26	NO AUX
5	NC FIRE	15	NC FIRE	25	NC AUX
4	COM FAULT	14	COM FAULT	24	NOT USED
3	NO FAULT	13	NO FAULT	23	NOT USED
2	+Vin	12	+Vin	22	MAN O <sub>1</sub>
1	-Vin	11	-Vin	21	-Vin

Figure 1—X2200 HART Wiring Terminal Identification




Figure 4—X2200 Detector Wired for Non-Isolated 0 to 20 mA Current Output (Sinking)




Figure 2—X2200 Detector Wired for Non-Isolated 0 to 20 mA Current Output (Sourcing)




Figure 5—X2200 Detector Wired for Isolated 0 to 20 mA Current Output (Sinking)

\*Nominal input impedance of PLC = 250 ohms.  
Maximum loop impedance including input impedance of PLC = 600 ohms.




Figure 3—X2200 Detector Wired for Isolated 0 to 20 mA Current Output (Sourcing)




Figure 6—Wiring the X2200 for Benchtop Testing/ Programming Using HART Protocol

## Multidrop Mode

Optical flame detectors are life safety devices and require the 0–20 mA loop for transmitting important detector status data. They should not be used in conjunction with multidrop mode. If multidrop mode is a requirement, the alarm and fault relay contacts must be connected directly to the safety system or fire panel for signalling purposes.

### NOTE

*RS-485 Modbus communication is not available on HART equipped models.*

### NOTE

*This addendum covers HART wiring only. Refer to the device instruction manual for NFPA-72 compliant releasing wiring diagrams.*

## HART DEVICE DESCRIPTION LANGUAGE

The HART protocol incorporates a concept called the Device Description Language (DD) that enables all suppliers of HART instruments to define and document their products in a single consistent format. This format is readable by handheld communicators, PCs and other process interface devices that support DD. DD enables full interoperability of devices, regardless of manufacturer, allowing full functionality from any HART device.

In the event that your Communicator does not establish communications with the X2200, ensure that the appropriate DDs for the X2200 have been programmed into your Communicator. To review the DDs programmed into your HART Communicator:

1. From the Main menu, access the Offline menu.
2. From the Offline menu, select New Configuration to access the list of device descriptions programmed into the HART Communicator.
3. Select Det-Tronics and review the list of models to determine if the X2200 DDs are installed in your Communicator.

If the X2200 DDs have not been programmed into the Memory Module, you must use the generic interface built into your HART Communicator.

The HART Communication Foundation manages a library of Manufacturer Device Descriptions, which are distributed to programming sites for inclusion in master devices. A complete listing

of the HCF DD Library is available for download in manufacturer and device type sequence at [en.hartcomm.org](http://en.hartcomm.org).

## DETECTOR WIRING

Refer to the X2200 instruction manual (form number 95-8549) for complete instructions regarding detector installation and wiring.

### NOTE

*X2200 detectors with HART do not support RS485 communication.*

### NOTE


*Power consumption specifications for the HART model are different than the standard model.*

## Power Consumption Specifications of X2200 Detector with HART Communication

Without heater: 2.5 watts at 24 Vdc nominal;  
4.5 watts at 24 Vdc in alarm.  
2.8 watts at 30 Vdc nominal;  
5.1 watts at 30 Vdc in alarm.  
Total power: 7.6 watts at 30 Vdc with EOL resistor installed.

EOL resistor must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

# HART MENU STRUCTURE



## X2200 ROOT MENU

When HART communication is established, the first menu displayed is the X2200 Root menu:

### X2200 Root Menu

- 1) Fire (Yes/No)
- 2) Fault (Yes/No)
- 3) Device Info Menu
- 4) Command Menu
- 5) Device Setup Menu

- 1) Fire (Yes/No)** Indicates “Y” if the device is in a fire alarm status — analog output is at 20 mA, fire alarm relay is actuated, and LED is red.
- 2) Fault (Yes/No)** Indicates “Y” if a fault condition exists. Go to “Device Info” and select “Status Info” to determine the nature of the fault.
- 3) Device Info Menu** Provides access to manufacturer and HART information, current device status, factory settings, and history logs.
- 4) Command Menu** This menu allows the operator to initiate a manual o<sub>j</sub> test and to perform various reset/clear functions.
- 5) Device Setup Menu** This menu allows various setup, configuration, and calibration functions.

## DEVICE INFO MENU

This menu allows access to a variety of “read-only” information.

### X2200 Root Menu


- 1) Fire (Yes/No)
- 2) Fault (Yes/No)
- 3) Device Info Menu
- 4) Command Menu
- 5) Device Setup Menu

### Device Info Menu

- 1) General Info Menu
- 2) HART Info Menu
- 3) Status Info Menu
- 4) Detector Settings
- 5) History Menu

- 1) General Info Menu** Factory information.
- 2) HART Info Menu** HART Specific Variables.
- 3) Status Info Menu** Current operating status and/or diagnostic information.
- 4) Detector Settings** Factory settings relating to relay operation, detector sensitivity, and response.
- 5) History Menu** Display log files: Alarm, Fault, General.


## GENERAL INFO MENU



- |                               |   |
|-------------------------------|---|
| <b>1) Manufacturer</b>        | Det-Tronics.  |
| <b>2) Model</b>               | X2200.  |
| <b>3) Serial Number</b>       | Serial number of device.  |
| <b>4) Part Number</b>         | Manufacturer's part number for this device.   |
| <b>5) Manufacture Date</b>    | Date of manufacture shown as XX/XX/XX (month/day/year).   |
| <b>6) Sensor Firmware</b>     | Firmware revision level of sensor module.   |
| <b>7) HART Firmware</b>       | Firmware revision level of HART Interface Board (HIB).  |
| <b>8) Real Time Clock</b>     | Current time and date settings of real time clock.  |
| <b>9) Write protect (Y/N)</b> | This indicates whether variables can be written to the device or whether commands that cause actions to be performed in the device can or cannot occur. |




## HART INFO MENU




- |                             |   |
|-----------------------------|---|
| <b>1) Universal rev</b>     | HART universal revision.  |
| <b>2) Fld dev rev</b>       | HART field device revision.   |
| <b>3) Final asmbly num</b>  | A number that is used for identification purposes and is associated with the overall field device.  |
| <b>4) Tag</b>               | Text that is associated with the field device installation. This text can be used by the operator in any way. Max of eight character input. |
| <b>5) Long tag</b>          | Text that is associated with the field device installation. This text can be used by the operator in any way. Max of 32 character input.    |
| <b>6) Date</b>              | Any date chosen by the operator to be used for any purpose. XX/XX/XXXX (month/day/year).  |
| <b>7) Descriptor</b>        | Text associated with the field device that can be used by the operator in any way.  |
| <b>8) Message</b>           | Text associated with the field device that can be used by the operator in any way.  |
| <b>9) Num req preams</b>    | HART specific synchronization messages.   |
| <b>10) HART PV Menu</b>     | Display HART specific primary variable (PV) items.  |
| <b>11) Condensed Status</b> | Device status condensed for HART handheld display.  |

# HART PV MENU



<b>1) PV Unit</b>	Not implemented for X2200.
<b>2) PV</b>	Not implemented for X2200.
<b>3) PV Sensor Unit</b>	Not implemented for X2200.
<b>4) PV USL</b>	Not implemented for X2200.
<b>5) PV LSL</b>	Not implemented for X2200.
<b>6) PV Minimum Span</b>	Not implemented for X2200.
<b>7) PV Damp</b>	Not implemented for X2200.
<b>8) PV AO</b>	Analog Output. The value that tracks the Digital Value representation, under normal operating modes.
<b>9) PV AO Alarm type</b>	Not implemented for X2200.
<b>10) PV % Range</b>	Percent of Range. The variable that tracks the Digital Value representation with respect to the range defined by the Lower Range Value and Upper Range Value, for normal operating modes. The units of this variable are always in percent.
<b>11) PV Xfer Function</b>	Not implemented for X2200.
<b>12) PV Range Unit</b>	Not implemented for X2200.
<b>13) PV URV</b>	Not implemented for X2200.
<b>14) PV LRV</b>	Not implemented for X2200.
<b>15) PV PV Snshr S/N</b>	Not implemented for X2200.


## CONDENSED STATUS



- |                            |  |
|----------------------------|--|
| <b>1) Xmtr Addstatus 0</b> | Fire Alarm<br>UV Alarm<br>oj Cal Alarm<br>Manual oj Active<br>Warmup   |
| <b>2) Xmtr Addstatus 1</b> | UV Pre Alarm   |
| <b>3) Xmtr Addstatus 2</b> | Fault<br>Manual UV oj Fault<br>Auto UV oj Fault<br>UV oj Cal Fault<br>Temperature Out of Range   |
| <b>4) Xmtr Addstatus 3</b> | Voltage Out of Range Fault<br>Manual oj at Start<br>Hardware Fault<br>HART Fault<br>Modbus Communication Fault<br>Incompatible Version |
| <b>5) Operating mode</b>   | Fault<br>Fire Alarm  |


## STATUS INFO MENU

This menu (read-only) shows extensive status information about the detector.




- |                                     |  |
|-------------------------------------|--|
| <b>1) Warm Up (Y/N)</b>             | Device is in the power-up time delay (warm-up) mode.   |
| <b>2) Fire (Y/N)</b>                | Indicates "Y" if the device is in a fire alarm status — analog output is at 20 mA, fire alarm relay is actuated, and LED is red. |
| <b>3) UV Alarm (Y/N)</b>            | Indicates "Y" if the UV detector is signaling an alarm.  |
| <b>4) UV Pre Alarm (Y/N)</b>        | Indicates "Y" if the UV detector is in a pre-alarm state. .  |
| <b>5) Auto UV oi Flt (Y/N)</b>      | Automatic UV oi Fault. Check viewing window and oi reflector plate for cleanliness.  |
| <b>6) Manual oi at Start (Y/N)</b>  | Manual oi at start. On power-up a manual Oi was started. Check the external input wiring.  |
| <b>7) Sensor Hdw. Fault (Y/N)</b>   | Sensor hardware fault.   |
| <b>8) HIB Hardware Flt (Y/N)</b>    | HART Interface Board hardware fault.   |
| <b>9) Internal Com. Flt (Y/N)</b>   | Internal communication fault.  |
| <b>10) Incompatible Fault (Y/N)</b> | Sensor module firmware version is not compatible with HART Interface Board.  |
| <b>11) Voltage Fault (Y/N)</b>      | Detector operating voltage is out of tolerance.  |
| <b>12) Hardware Menu</b>            | Refer to sub-menu.   |
| <b>13) oi Menu</b>                  | Refer to sub-menu.   |

## HARDWARE MENU



- |                              |   |
|------------------------------|---|
| <b>1) Temperature</b>        | Actual integral temperature of detector.  |
| <b>2) Temp Range Fault</b>   | Detector integral temperature out of range — Operating range: $-40^{\circ}\text{F}$ to $+167^{\circ}\text{F}$ ( $-40^{\circ}\text{C}$ to $+75^{\circ}\text{C}$ ). |
| <b>3) Voltage</b>            | Actual detector supply voltage must be 18 to 30 Vdc.  |
| <b>4) Voltage Fault</b>      | Supply voltage is out of range. Operating voltage must be 18 to 30 Vdc.   |
| <b>5) Manual oi at Start</b> | Manual oi at start. On power-up a manual oi was started. Check the external input wiring.   |


# Oj MENU



- 1) Consecutive UV Oj Fails** Allowable number of consecutive UV Oj failures to produce a fault. Factory set to three (minutes). This is the time between fault occurrence and annunciation
- 2) Oj Calibrate Active** Oj calibration is in progress.
- 3) UV Oj Cal Fit** UV Oj calibration has detected a fault condition.
- 4) Manual Oj Active** A manual Oj test is in progress.
- 5) Manual UV Oj Fit** Manual UV Oj fault. Check UV viewing window and Oj reflector plate cleanliness.

## DETECTOR SETTINGS


This menu shows factory settings relating to relay operation, detector sensitivity, and response.



- 1) UV Mode** UV Mode: Standard or Arc.
- 2) Arc Rejection** Detector ARC Rejection setting: Low, Medium, High, or Very High.
- 3) UV Sensitivity** Detector UV sensitivity setting: Low, Medium, High, or Very High.
- 4) Auto Oi Enabled** Auto Oi enabled. If (Y) an Oi test will be conducted periodically without manual input.
- 5) Fire Relay (NL/L)** Fire Relay: Latching (L) or Non-Latching (NL).
- 6) Fault Relay (NL/L)** Fault Relay: Latching (L) or Non-Latching (NL).
- 7) Aux Relay (NL/L)** Aux Relay: Latching (L) or Non-Latching (NL).
- 8) Heater Disabled** Heater disabled. If (Y) the optics heater is not enabled to prevent condensation and icing.
- 9) Aux Function** Aux function: Pre Alarm or UV Alarm.
- 10) Aux Relay (NE/NDE)** Aux Relay: Normally Energized (NE) or Normally De-Energized (NDE)

## HISTORY MENU


This menu provides historical information about the detector. Up to 32 events in each of the three categories will be kept in non-volatile memory. When the log is full, the oldest event will be overwritten. The most recent event will be displayed first.



- 1) Alarm Log** Scroll through 32 Alarm Logs with time, date, and temperature stamp.
- 2) Fault Log** Scroll through 32 Fault Logs with time, date, and temperature stamp.
- 3) General Log** Scroll through 32 General Logs with time, date, and temperature stamp.

## COMMAND MENU

The Command Menu allows the operator to initiate a manual o<sub>j</sub> test and also to perform various reset/clear functions.



### 1) Start Passive o<sub>j</sub>

A passive o<sub>j</sub> test command checks the cleanliness of the detector's optical surfaces. This calibrated o<sub>j</sub> test confirms the ability of the detector to respond correctly to an IR signal. Fire and fault relays as well as 0–20 mA current loop output are unaffected by this test. A red LED signals a successful test, and an amber LED signals a failed test. The general log will indicate either “Man o<sub>j</sub> Pass” or “Man o<sub>j</sub> Flt.”

### 2) Start Active o<sub>j</sub>

#### CAUTION

*An active o<sub>j</sub> test generates an actual Fire Alarm Output. All fire response equipment must be bypassed/disabled prior to testing to prevent unwanted output actuation.*

An active o<sub>j</sub> test performs an o<sub>j</sub> test with all detector outputs fully operational. Fire and fault relays as well as the 0–20 mA loop are “live.”

If the test is successful:

- Fire relay = Alarm
- Fault relay = no fault
- Current output is 20 mA
- LED turns red
- General log indicates “Man o<sub>j</sub> Pass”
- Alarm log indicates “Fire Alarm”

If the test is unsuccessful:

- Fire relay = No Alarm
- Fault relay = Fault
- Current output is 2 mA
- LED turns yellow
- Fault log indicates “Man o<sub>j</sub> Flt”

### 3) Clear o<sub>j</sub> Fault

If the cause of the fault has not been corrected, subsequent o<sub>j</sub> faults will occur.

### 4) Reset Latches

Latching relays are reset and LED turns green.

### 5) Master Reset

This function re-initializes the microprocessor, resets the operating software, and initiates a hardware reset for both the sensor and the HART interface. Latched relays are reset.

### 6) Clear Data Log

This function resets the HART data log history. To view the logs, go to “Device Info Menu” and select “History Menu.”


### 7) HART Command Menu

This menu performs various diagnostic and/or service functions.



## HART COMMAND MENU


The HART Command Menu allows the operator to perform diagnostic and service functions as follows:



- 1) Self test** Internal tests are performed and any detected problems are reported in "Status Info." If successful, indication will be "No Device Info on Self Test."
- 2) Master Reset** This function re-initializes the microprocessor, resets the operating software, and initiates a hardware reset for both the sensor and the HART interface. Latched relays are reset.
- 3) Loop test** This test allows the operator to manually set the analog signal output at 1, 2, 3, or between 4 and 20 mA in increments of 2 (4, 6, 8, etc.). When the loop test is completed, ensure that the current loop is returned to automatic operation.

## DEVICE SETUP MENU


This menu allows various setup, configuration, and calibration functions. When Write Protect is off, these menus allow the operator to reconfigure or write new variables to the device.



- 1) Configuration Menu**
- 2) Calibration Menu**
- 3) Write Protect**
- 4) HART Setup**
- 5) Real Time Clock**

Refer to the appropriate sub-menus for details.

## CONFIGURATION MENU



### 1) Cons UV $o_j$ Fails

Allowable number of consecutive UV  $o_j$  failures to produce a fault. Factory set to three (minutes). This is the time between fault occurrence and annunciation.


### 2) Time Delay

Time Delay before alarm is indicated (0 to 15 seconds). Factory default is zero seconds.

**Important:** In addition to lengthening the time period between the outbreak of a fire and the fire alarm, a time delay can also affect sensitivity. Consult the factory for guidance before setting a time delay over five seconds.

**Note:** FM Approval covers the detector's performance with zero time delay only.

## CALIBRATION MENU



### 1) Loop test

This test allows the operator to manually set the analog signal output at 1, 2, 3, or between 4 and 20 mA in increments of 2 (4, 6, 8, etc.). When the loop test is completed, ensure that the current loop is returned to automatic operation.

### 2) D/A trim

This function allows adjustment of the 0–20 mA span factor.

#### **NOTE**

*Trim in increments of 0.1 mA resolution only.*


### 3) Calibrate $o_j$

This procedure calibrates the  $o_j$  test signal for the UV sensor.

1. Bypass/disable all Alarm outputs connected to the detector.
2. Thoroughly clean the sensor and  $o_j$  reflector for the UV sensor. Check the  $o_j$  source openings for contaminants and clean as needed.
3. Cover the detector with the provided cover.
4. Initiate  $o_j$  Calibration. The detector performs the calibration automatically and notifies the operator upon completion. The procedure takes approximately two minutes.
5. Upon completion of  $o_j$  calibration, remove the cover and return all alarm outputs to service.

## WRITE PROTECT

This function enables the operator to enable/disable password and write protection capability, as well as to enter or change a password. The device is provided from the factory with Write Protect off. With Write Protect on, the use of a password is required to enable writing to the device.



### 1) Set Password

The password is used to validate the command to enable or disable writes in the device. (The factory default password is: 1\*\*\*\*\*. Once the password has been changed, the default password is no longer valid.)

To change the password:

1. Select "Set Password" and enter the password. Hit "Send."
2. If enabled, disable Write Protect. Hit "Send."
3. Select "Set Password" and enter a new password. Do not hit "Send" yet.
4. From within the "Set Write Protect" menu, select "Change Password."  
Hit "Send."

### CAUTION

*Always record the new password. If the password is forgotten, the device must be returned to the factory for re-programming.*


### 2) Set Write Protect

With Write Protect enabled, variables cannot be written to the device and commands that cause actions to be performed in the device cannot occur.

**3) Write protect (Y/N)** This indicates whether or not Write Protect is enabled.

## HART SETUP


This menu allows editing of the following functions:



- 1) Poll addr** Address used by the host device to identify a field device. Note that if it is set to an address other than "0," the Detector will output 1 mA.
- 2) Final assembly num** A number that is used for identification purposes and is associated with the overall field device.
- 3) Tag** Text that is associated with the field device installation. This text can be used by the operator in any way. Max of eight character input.
- 4) Long tag** Text that is associated with the field device installation. This text can be used by the operator in any way. Max of 32 character input.
- 5) Date** Any date chosen by the operator to be used for any purpose. XX/XX/XXXX (month/day/year).
- 6) Descriptor** Text associated with the field device that can be used by the operator in any way.
- 7) Message** Text associated with the field device that can be used by the operator in any way.

## REAL TIME CLOCK

To set the real time clock, enter the current time and date information into the appropriate fields.



- 1) RTC Seconds** 0 to 59
- 2) RTC Minutes** 0 to 59
- 3) RTC Hours** 0 to 23
- 4) RTC Date** 1 to 31
- 5) RTC Month** 1 to 12
- 6) RTC Year** 0 to 99



95-8638



FlexSonic® Acoustic  
Leak Detector



X3301 Multispectrum  
IR Flame Detector



PointWatch Eclipse® IR  
Combustible Gas Detector



FlexVu® Universal Display  
with GT3000 Toxic Gas Detector



Eagle Quantum Premier®  
Safety System

Specifications subject to change without notice.

All trademarks are the property of their respective owners.

© 2020 Detector Electronics Corporation. All rights reserved.



**Corporate Office**  
6901 West 110<sup>th</sup> Street  
Minneapolis, MN 55438 USA  
[www.det-tronics.com](http://www.det-tronics.com)

Phone: +1 952.941.6665  
Toll-free: +1 800.765.3473  
Fax: 952.829.8750  
[det-tronics@carrier.com](mailto:det-tronics@carrier.com)